

# **STORM DRAIN STENCILING PROGRAM**

---

## **STENCILING INSTRUCTIONS**

- STEP 1: CLEAN THE SURFACE:** Bring a broom or stiff brush. Brush off the surface in which you are stenciling to get any excess dirt off.
- STEP 2: BLUE BACKGROUND:** Position rectangular stencil on the street side of the storm grate or inlet out of the way of flowing dirt and leaves. Spray the first coat of blue *neatly* across the surface of the pavement to be stenciled. Let it set for 5 minutes or until dry.
- STEP 3: WHITE LETTERING:** Place lettering stencil on top of the blue rectangle. Then *lightly coat with white paint (2-3 times)* until covered (*do not overspray or spray heavily*). Paint should be dry in 8-10 min.
- STEP 4: CLEAN STENCIL:** Place wet stencil on a piece of plastic or cardboard upon completion of each drain. Wipe as much wet paint as possible off the stencil with a paper towel or cloth rag. This will allow us to reuse the stencil many times.
- STEP 5: PLEASE RETURN ALL STENCILING EQUIPMENT TO:**

Watershed Stewards  
WSU Cooperative Extension  
11104 NE 149 Street, Building C-100  
Brush Prairie, WA 98606